







# JØTUL F 620 LB



F 620 B





F 620 P



F 620 LB




F 620 B HT




F 620 B / F 620 P / F 620 LB / F 620 B HT  
- With retrofitted cast iron side



FR



FL




F



F 620 B / F 620 P / F 620 LB / F 620 B HT  
- With retrofitted cast iron side and convection kit side  
- With retrofitted convection kit rear



FR

Convection kit side





FL

Convection kit side




Convection kit rear




F 620: Minimum distance to combustibile wall protected by approved fireproof wall

Combustible wall  
Firewall (See Chapter 3.3 in the manual)


F 620 B






F 620 P



F 620 LB




F 620 B HT




F 620 B / F 620 P / F 620 LB / F 620 HT  
- With retrofitted cast iron side

FR



FL



F

